## Step 1

Unzip the bottom cloth and line up the holes in the Seats Units with the inserts in the Panel.

## Fixings supplied:



M8 x 60mm Bolt, Washer,

8No. Fixings supplied to secure Seats to Panel.



## Step 2

Loosely locate the bolts into the inserts. Tighten the <u>upper bolt in the back first</u>. Tighten all fixings, securing the Seat Units in place. Repeat for other side.



**Step 3**Carefully Tip the Panel and two Seat Units onto the feet.





## EVETTE PANEL INSTALLATION INSTRUCTIONS



Chapel Lane, High Wycombe, Buckinghamshire HP12 4BG

t: +44 (0) 1494 448000 w: verco.co.uk